

Non Contact Voltage Sensor

Model
SNCV1

The SNCV1 non contact voltage tester senses live voltage without touching the object being tested so you know whether a wire is HOT or NOT.

Features

- Senses 24VAC to 440VAC.
- LED & buzzer indicators with analog feel.
- Differentiates between hot and neutral.

Specifications

Range:	24VAC to 440VAC.
Operating environment:	14 to 131°F
Safety:	UL 1244, MAX 600VAC, CAT III, UL &cUL listed
Battery:	LR44 x 2 (included)

Operator's Guide


TEST ON A KNOWN LIVE WIRE BEFORE USING.

Voltage Test


1. Place the probe tip of SNCV1 close (~1/4") to object being tested for voltage.
2. If a voltage above 24VAC is detected, the LED will light and the buzzer will sound. The indicators get louder and brighter as the voltage rises or as the probe tip becomes closer to the source fo voltage.

Find a Break in a Power Cable

Scan power cable to determine the point where voltage is lost.



More pocket tools from Fieldpiece



SIR2 Wide Angle IR Thermometer with Laser

SPK1 Pocket Knife Style Thermometer



580 West Central Avenue, Suite A
Brea, California 92821
Phone: (714) 257-9060
Fax: (714) 257-9069
www.fieldpiece.com
MADE IN CHINA



Model: SNCV1

8 72641 00117 9